

# FITTING INSTRUCTIONS

## HUB KIT & QUICK RELEASE (non horn)

### CONTENTS

1 x Quick release unit  
6 x Hub fixing screws  
1 x horn button retaining ring

### OPTIONAL PARTS

1 x Nero Steering wheel  
1 x Horn button  
1 x Centre ring/surround  
6 x Fixing screws

### FITTING

1. Start by removing the centre cap of the steering wheel to expose the bolt which secures the steering wheel to the steering column.



2. Remove the bolt from the steering column. Keep hold of the bolt as it will be replaced later in the process.



3. With the bolt removed pull the steering wheel towards you, it may require a few taps from behind to release the wheel from the spline.



4. With the steering wheel removed, place the hub kit onto the exposed spline on the steering column.



5. Replace the bolt and tighten to secure the hub kit to the steering column.



6. Separate the quick release unit into the 2 halves.

7. Secure the rear part of the quick release to the hub kit using the 6 fixing screws provided.



8. Once the rear part of the quick release is secured to the hub kit, replace the front half (it should push into position click and lock.)



9. Before fitting the steering wheel the horn button should be fitted.

10. To do this the horn button retaining ring must be placed into the back of the steering wheel.

11. Push the horn button into the retaining ring from the front side of the steering wheel. (Take care not to break the legs off the horn button)





12. Secure the steering wheel to the quick release using the 6 x hub fixing screws.



13. Fit the centre ring/surround to the steering wheel using the 2 screws provided.

14. Fitment complete.

